



**DIAMONDBACK**

DiamondBackCovers.com / 800 935 4002

# BED RAIL CAP SHIMS

'07-UP TOYOTA TUNDRA

## INSTALLATION GUIDE

MISC-15


**15 minutes**  
Normal install time

Keep an eye out for these icons:

**! IMPORTANT!**  
Important installation information

**★ Helpful Hints**  
Tips to assist installation

### PARTS INCLUDED:



Shims  
(24, 32 or 40)

### TOOLS REQUIRED:



Rubbing  
Alcohol



Lint-Free  
Cloth

### PRE-INSTALLATION NOTE:

To ensure the shims stick, make sure the surface temperature of your bed rail caps is at least 50°F and will remain so for at least a day.



## REMOVE THE BED RAIL CAPS

**1** Standing on the driver side near the cab and working tailward, pop out each of the bed rail cap's inboard retainer clips one by one by using your fingertips to pry up on the cap's vertical leg.



**!** Be careful not to bend or crease the bed rail cap.

**2** Standing at the tail and working cab-ward, use one hand as a wedge to pop out each remaining retainer clip one by one.



**3** Repeat steps 1 & 2 on the passenger side.

# INSTALL THE SHIMS

**4** Use rubbing alcohol and a lint-free cloth to clean the shallow, rectangular recesses on the underside of the caps where you will put the shims. If your Tundra has a:

- 5.5-ft bed: clean the recesses located between 24" and 45" from the tail end of the caps
- 6.5-ft bed: between 27" to 53"
- 8' bed: between 32" to 68"

**5** Allow the caps to dry.

**6** Split the bag of shims into two equal piles (one pile per cap).

**7** In the recesses you've cleaned, peel and stick the shims evenly spaced, two by two, parallel to length of the caps.

**8** Starting near the cab and working tailward, reinstall the caps by aligning their retainer clips with the perforations on the bed rail and smacking them through with the heel of your hand.

