

Got a RamBox?

Read the below instructions specific to your truck:

Before installing your cover:

1. Affix the square-tube shims to the top of the utility rails, their:
 - a. forward ends tight against the bulkhead,
 - b. sides tight against the bed wall, and
 - c. adhesive strips to the bed-wall side of the slot in the top of the utility rails.

During the install:

2. Place the cover on top of the shims, with the leading edge of the cover flush with the front of the bulkhead and the tailgate panel sitting on top of the tailgate.
3. Use two 9/16" wrenches to tighten your clamps.
4. When it comes to your lock rods, adjust and position them so that:
 - a. with the lock handle in the open position, the rod tips clear the *utility rail*,
 - b. with the handle in the closed position, the rod tips do not strike the bed walls,
 - c. the rods point downward, and
 - d. they are tight against the underside of the top portion of the utility rail.
5. Install the cover on top then to be installed on top of the shims so that the front of the cover is flush with front of bulkhead and the tail panel lays on top of the tailgate.