



**DIAMONDBACK**

DiamondBackCovers.com / 800 935 4002

# BULKHEAD PREP KIT



Install Video

## INSTALLATION GUIDE

**BH-1**


**10 minutes**  
Normal install time

Keep an eye out for these icons:

**! IMPORTANT!**  
Important installation information

**★ Helpful Hints**  
Tips to assist installation

### PARTS INCLUDED:



Bulkhead  
Weatherstrip Kit


### TOOLS REQUIRED:



Isopropyl Alcohol



Clean, Lint- Free Cloth



Scissors

## PRE-INSTALLATION NOTE (REVIEW ALL OTHER INCLUDED INSTALLATION GUIDES BEFORE BEGINNING)

To ensure the sealing mount tape adheres properly, make sure the temperature of the cleaned surface is at least 50°F and will remain so for at least a day.



## INSTRUCTIONS

**1** Clean the top of the bulkhead thoroughly with a clean, lint-free cloth and Isopropyl Alcohol. Allow to dry.



**!** It is very important that the top of the bulkhead be both dry and absolutely free of dirt, oil, or any other contaminants prior to application of the weatherstrip.



**★** The bulkhead weatherstrip will stick to a spray-in bed liner just fine.



**2** If you have a bed liner that laps over the bulkhead, you may see a 1/4" gap at each side of the top of the bulkhead between the liner and the bed rail caps. Fill the gap with silicone.

**3** Affix the **weatherstrip** to the top of the bulkhead so it's:

- tight against the interior edges of the bed rail caps at both ends, and
- aligned with the perimeter weatherstrip of the cab panel if you have a DiamondBack HD, SE, or SwitchBack, or
- in a straight line as far toward the cab as possible while maintaining contact with the bulkhead along its entire length if you have a DiamondBack 270 or 180.

**!** Press down firmly with your thumb on the weatherstrip along its entire length.

**!** Never stretch the weatherstrip when applying. If you do, its adhesive will fail.



**4** After you have installed your cover, leave its front panel(s) closed and locked for 24 hours to allow the bulkhead weatherstrip adhesive, which is pressure-activated, to fully cure.

**24 hours**  
Cure time